



Application Note

Subject: Printing one logo on a long receipt

Products Covered in This Application Note: TSP100

Date: January 24, 2008

The following procedure outlines the steps required to create a long receipt. The purpose is to allow the TSP100 futureprint to work with the longer page and only place a top logo and coupon at the very top and bottom of the printed receipt


Step 1

Create or edit the 72 mm x receipt entry for paper sizes in Server properties

Start, settings, printers and faxes, File, server properties




Locate the form 72 mm x receipt



And increase the length to the longest you will ever print.

If you prefer you can create a new form with this new length. I.e.



Step 2


Ensure that this is the default size in the driver.

Typically the default paper size is set to letter.


You may need to change this paper size in 2 or more places.

Start, settings, printers and faxes, TSP100, Printing preferences.

Ensure the page size is the newly created form.




Start, settings, printers and faxes, tsp100, properties, device settings



And finally in Advanced printing defaults


Start, settings, printers and faxes, TSP100, properties, advanced, printing defaults, Advanced.



Step 3


Confirm that the long paper size is available in WORDPAD.

Open Wordpad, print and check that the TSP100 is selected.




Click on apply and then cancel.

Check in page setup that you now have a page with 0 left and right margins and that the page is the length you expected.



Create a very long receipt.



Step 4

Adding a top and bottom logo.

Inside the TSP100 configuration page, Add a top and bottom logo.

Logo Printing

Top Image List

logo1	Center	Add
		Delete
		Print All <input type="button" value="v"/>

Bottom Image List

survey	Center	Add
		Delete
		Print All <input type="button" value="v"/>

Print the receipt from word confirming that the top and bottom logo only appear on the page once.